Batman

03 Nov 17:00 Duty six : Green

Start	Time	Activity	Requirements	Instructions	Scouter
	•	Batman uses a lot of gadgets	and tools to help him be a superhero. He has a team of people	e who build the gadgets for him	
03 Nov 17:00	5	Activities : Opening	Register, beans, flag, totem and skin	Grand Howl Flag Break Register Inspection - belts and shoes	Akela
		Could you ma	ake gadgets for batman? You would first need to know how to	use some tools	
03 Nov 17:05	10	Game : Find the Tools		Scatter a variety of tools (or pictures of tools) around the play area. Cubs to search for and bring back the tools and place on a prepared board/sheet of cardboard where the outline of the tools have been drawn. Once all the outlines have been filled, the game is done. End with a discussion on each tool and how to look after them (Repairs badge requirement to know any four tools). Use screwdriver, vice, hammer, wood plane, brace and bit, pliers, adjustable wrench, saw, g-clamp	Akela
		Different	glues work for different projects. What should we use to fix the		
03 Nov 17:15	20	Activities : Simple repairs	Various items requiring minor repair	Using glue, repair the item. Use clamps to hold together until glue dries (or other ways of holding together). Use toothpick to apply glue neatly.	Akela
			Good job!! Take a break		
03 Nov 17:35	5	Activities : Juice and biscuits		Juice and biscuit break	Akela
	- -		Batman needs his sleep but a leaky tap is keeping him awak	e	
03 Nov 17:40	15	Activities : Repair a leaky tap	tap, shifting spanner, washer, cloth	Before you get started	Akela
				If you are in any doubt about the technique for repairing a tap, it is best to seek professional help.	
				To fix a leaking tap, first, you must safely turn off the water supply to that tap. This is easiest when isolation valves are situated close to the tap, on its supply pipes. With the valve design shown in this guide, if the slot of the screw is aligned with the pipe, thenthe valve is on. A quarter turn of the screw, so that the slot is running across the pipe, will turn the valve off. You can normally identify whether a tap uses rubber washers or ceramic discs by turning the tap handle. If it can only rotate a quarter or half a turn, it will normally be a ceramic disc type tap.	
				If it rotates more than this, it will generally be a rubber washer type. Some single-lever operated mixer taps have a ceramic cartridge that is often very specific to a particular manufacturer. Replacements may need to be specially ordered. With ceramic disc taps, you replace the whole valve. With	

rubber washer taps, you only need to replace the small washer.

Worn O-rings are a common cause of leakage on kitchen taps, but you may also find O-rings on the valve body in some taps. If you fix a washer and the tap is still leaking, check for other Orings and seals on the valve body to see if they are worn.

Protect rubber washers by taking care when turning taps off and on. Most become worn and need replacing because the tap has been overtightened when turning it off. A tap with a compression valve and rubber washers will always drip once or twice when you turn it off – it is not necessary to tighten and tighten again to avoid this. Allow these residual drips without feeling the need to tighten the tap more.

Gain access to the tap body

Before working on a tap, turn off the water supply – easiest when isolation valves are located close to the tap. Run tap to remove water from the pipes.

To get the tap head off, you need to access the handle screw. This will often be hidden under a cap on the handle, which will be simple to unscrew.

Alternatively, the top cap of the tap may be flipped off using a slot-head screwdriver. Carefully push under the cap edge and ease off.

Another possibility may be to simply lift off the cap with your fingers. Tap designs vary, as do these access points. Some may even require an Allen key.

For single-lever taps, it is often necessary to flip off the hot and cold indicator tab with a slot-head screwdriver to reveal a tiny retaining screw. Be careful not to scratch the chrome finish of the tap.

e

Any parts that you take off, lay out in order for easy reassembly. This ceramic cartridge can be replaced with an adjustable spanner in a similar way to the ceramic disc valve replacement shown opposite.

Replace a rubber washer

		The bat signal is a	s big light that needs to be plugged in. But the plug has come loos	Remove the handle cap if there is one, to expose the handle screw, and unscrew it to remove the handle. 2 Set aside the tap handle, along with the shroud if there is one, to reveal the tap valve underneath. 3 Use an adjustable spanner to unscrew the tap valve so that you can remove the valve from the tap seat. 4 Unscrew or flip off the washer and replace with another. Reverse the process to reassemble the tap.	
03 Nov 17:55	20	Activities : Wiring a Plug	plugs, wires, cutters, screwdrivers, instructions	Wiring a Plug	Akela
				 Bare the ends of the three wires inside the electrical cord for about half a centimeter, by cutting away the plastic insulation. 	
				Gently twist the strands of copper wire with your fingers until each strand is tight.	
				3. Fold over the twisted strands.	
				 Remove the plug cover by either "snapping" or unscrewing it. 	
				5. Unscrew the little screws on each of the plug's pins.	
				Insert the twisted copper wires into the holes in the pins.	
				The green and yellow wire must always be inserted into the top pin.	
				 The blue wire is inserted into the left pin (the pin is marked with a blue spot or the letter N). 	
				9. The brown wire is inserted into the right pin (the pin is marked with a brown spot or the letter L)	
				10. Tighten the little screw on each of the plug's pins.	
				11. Make sure the electrical cord is firmly gripped by the arrestor clips.	
				12. Replace the cover of the plug.	
				Bare the ends of the three wires inside theGently twist the strands of copper wire with your	

				electrical cord for about half a centimeter, by cutting away the plastic insulation.	fingers until each strand is tight. Fold over the twisted strands.	
				Remove the plug cover by either "snapping" or unscrewing it.	Unscrew the little screws on each of the plug's pins.	
				Insert the twisted copper wires into the holes in the pins. The brown wire is inserted into the right pin (the pin is marked with a brown spot or the letter L)	Tighten the little screw on each of the plug's pins.	
				Make sure the electrical cord is firmly gripped by the arrestor clips. The green and yellow wire must always be inserted into the top pin. The blue wire is inserted into the left pin (the pin is marked with a blue spot or the letter N).	Replace the cover of the plug	
03 Nov 18:15	10	Activities : Catapult	fits in the spoon)	 Make a stack of 7 popsicle sticks them together on both ends. Make a stack of 2 popsicle sticks them together on one end only. Pull the 2 popsicle sticks apart an popsicle sticks between them. Use two rubber bands, secure the popsicle stick. Place the ball onto the spoon. Hold the catapult with one hand, to down the spoon. 	and use a rubber band to tie Id wedge the stack of 7 9 plastic soon to the upper	Akela

				7. Release the spoon and watch the ball fly!	
We are saying goodbye to Lisy who is going up to Scouts this week.					
03 Nov 18:25	5	•	Badges, certificates	Announcements Badge handouts	Akela
				Grand Howl Flag Down Prayer Dismiss	

Programme prepared on 09 May 00:37